# ABLELink®
# SW5002 Wireless Serial Server

## User Manual

Version 1.0

Updated on November, 2007

TEL: 886-3-5508137

FAX: 886-3-5508131

http://www.atop.com.tw

# Important Announcement

The information contained in this document is the property of Atop Technologies, Inc. and is supplied for the sole purpose of operation and maintenance of products of Atop Technologies, Inc. No part of this publication is to be used for any other purposes, and it is not to be reproduced, copied, disclosed, transmitted, stored in a retrieval system, or translated into any human or computer language, in any form, by any means, in whole or in part, without the prior explicit written consent of Atop Technologies, Inc.

# Published by

## Atop Technologies, Inc.

2F, No. 146, Sec. 1, Tung-Hsing Rd.

Jubei, Hsinchu 30261

Taiwan, R.O.C.

Tel: 886-3-5508137

Fax: 886-3-5508131

www.atop.com.tw

Copyright © 2007 Atop Technologies, Inc. All rights reserved.

All other product names referenced herein are registered trademarks of their respective companies.

# FCC WARNING

## Class B for this product

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**FCC Caution: Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.**

**IMPORTANT NOTE:**

## FCC Radiation Exposure Statement:

This product complies with FCC radiation exposure limits set forth for an uncontrolled environment. This model should be installed and operated with minimum distance 20cm between the radiator & your body.

This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. IEEE 802.11b/g operation of this product in the U.S.A. is firmware-limited to channels 1 through 11.

# UL NOTICE FOR POWER SUPPLIER

All the series of SW5002 products are intended to be supplied by a Listed Power Unit marked with “LPS”, “Limited Power Source” or “Class 2” and output rate 9~48VDC, 1.0A minimum. Or, use the recommended power supply in “Optional Accessories”.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# Contents

**1. Introduction ..... 1**
1.1. Overview ..... 1
1.2. Features ..... 1
**2. Getting Started ..... 2**
2.1. Packaging Include ..... 2
2.2. Ordering information ..... 2
2.3. Interfaces ..... 2
2.4. Installation Procedures ..... 3
**3. Software Setup ..... 4**
3.1. Default Settings ..... 4
3.2. IP Assignment ..... 5
*3.2.1. Configure IP by monitor.exe utility ..... 5*
*3.2.2. Configure IP by web server ..... 6*
*3.2.3. Configure IP by Telnet utility ..... 6*
*3.2.4. Auto IP with DHCP ..... 6*
3.3. TCP/IP Port Number ..... 6
**4. Application Connectivity ..... 7**
4.1. TCP & UDP Protocols ..... 7
*4.1.1. Transmission Control Protocol (TCP) ..... 7*
*4.1.2. User Datagram Protocol (UDP) ..... 7*
4.2. Connectivity Topology ..... 7
*4.2.1. Virtual COM Mode ..... 8*
*4.2.2. Tunneling Mode ..... 9*
**5. Configure SW5002 by web interface ..... 12**
5.1. Login to System ..... 12
5.2. General Information ..... 12
5.3. Network Configuration ..... 15
*5.3.1. LAN Settings ..... 17*
*5.3.2. WLAN Settings ..... 17*
*5.3.3. DNS Settings ..... 17*
*5.3.4. SNMP Settings ..... 18*
5.4. Wireless Configuration ..... 18
*5.4.1. Wireless Detail Settings ..... 19*
*5.4.2. Sample Wireless Application Cases ..... 20*
5.5. COM Port Configuration ..... 22
*5.5.1. Link Mode Settings ..... 23*
*5.5.2. TCP Server Mode ..... 23*
*5.5.3. TCP Client Mode ..... 24*
*5.5.4. UDP Mode ..... 24*
*5.5.5. Serial Settings ..... 25*

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

*5.5.6. Delimiter Settings* ..... *26*
5.6. Configure System ..... *26*
*5.6.1. Configure Time by NTP Service* ..... *26*
*5.6.2.* Configure WLAN Region ..... *27*
*5.6.3. Change the Password* ..... *27*
*5.6.4. Restoring Factory Default* ..... *28*
*5.6.5. Restart System* ..... *28*
**6. Telnet Configuration ..... 30**
6.1. General Information ..... 31
6.2. Networking Configuration ..... 32
*6.2.1. LAN Settings* ..... *33*
*6.2.2. DNS Settings* ..... *33*
*6.2.3. SNMP Settings* ..... *34*
6.3. Wireless Configuration ..... 32
*6.3.1.* Wireless IP, Netmask, Gateway, and IP mode Settings ..... *33*
*6.3.2.* Configure Region ..... *34*
*6.3.3. Site Survey* ..... *34*
*6.3.4. Manual Wireless Settings* ..... *35*
*6.3.5. Configure Ad-Hoc Mode:* ..... *36*
*6.3.6. Configure Infrastructure Mode* ..... *37*
6.4. COM Port Configuration ..... 41
*6.4.1. TCP Server Mode for Link Mode* ..... *42*
*6.4.2. TCP Client for Link Mode* ..... *43*
*6.4.3. UDP for Link Mode* ..... *43*
*6.4.4. Serial Settings* ..... *44*
*6.4.5. Packet Delimiter* ..... *45*
6.5. Security Configuration ..... 46
*6.5.1. Change the Password* ..... *47*
**Appendix A. Using Virtual COM ..... 48**
*A.1. Pre-installation Requirements* ..... *48*
*A.2. Applying to the Serial Server* ..... *48*
*A.3. Virtual COM Communication* ..... *49*
**Appendix B. Configuration Utility & SNMP ..... 53**
*B.1. Monitor.exe* ..... *53*
*B.2. SNMP Network Management Platform* ..... *55*
*B.3. An Example: Using NetworkView* ..... *55*
**Appendix C. Upgrading System Software ..... 58**
*C.1. System Upgrading Procedures* ..... *58*
*C.2. Critical Issues in Upgrading Process* ..... *59*
**Appendix D. Specifications ..... 60**
*D.1. Hardware Specifications* ..... *60*
*D.2. Software Specifications* ..... *61*

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

D.3. Pin Assignments ..... 61
D.4. Beep & LED Status ..... 61

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# 1. Introduction

## 1.1. Overview

SW5002 Wireless Serial Server is a gateway between wireless LAN or Ethernet (TCP/IP) and RS-232/RS-485 communications. It allows almost any serial devices to be connected to a new or existing wireless network. The information transmitted by Serial Server is transparent to both host computers (IP network over wireless LAN or Ethernet) and devices (RS-232/RS-485). Data from the wireless LAN or Ethernet (TCP/IP) is transmitted to the designated RS-232/RS-485 port and data from RS-232/RS-485 port is transmitted to the Wireless or Ethernet (TCP/IP) transparently.

In the computer integration manufacturing or industrial automation area, Wireless Serial Server is used for field devices to direct connect to network. Terminal Server (main control program run in SW5002) transforms whatever data received from RS-232/RS-485 to TCP/UDP port then connects devices to the IP network via a single application program or multiple application programs.

Many control devices provide the ability to communicate with hosts through RS-232/RS-485 however RS-232/RS-485 serial communication has its limitations. For instance, it is hard to transfer data through a long distance. With SW5002, it is possible to communicate with a remote device in the Intranet environment or even in the Internet and thus, increases the communication distance dramatically.

Flexible configuration options enable this unit to be setup remotely over IP network by Telnet, web browser, or Window utility. Packed in a rugged DIN Rail mountable case and 9~48V DC power input range, SW5002 is ideal for almost any industrial and manufacturing automation.

## 1.2. Features

- Dual-port DIN-Rail mounting module.
- Metal housing with IP50 standard.
- 15KV ESD protection for serial ports
- IEEE 802.11g 54Mbps wireless network connectivity
- Support UDP, TCP server and client protocols for Virtual COM mode and pair connection
- Selectable RS-232/RS-485/RS-422 serial mode by software
- Configurable via console, telnet, built-in web server and Windows-based utilities
- Standard 2.4GHz High-gain antenna
- Upgradeable firmware via network

Copyright © 2006 Atop Technologies, Inc.
All rights reserved

# 2. Getting Started

## 2.1. Packaging Include

- Atop Wireless Serial Server x 1
- 5 pins Terminal Block for Serial Connector (TB model only) x 2
- 3 pins Terminal Block for Power Connector (TB model only) x 1
- 4 dBi Antenna x 1
- Wall mount kits x 2
- Atop Wireless Serial Server quick start guide x 1
- Product CD containing configuration utility x 1

❋ **NOTE: Notify your sales representative if any of the above items is missing or damaged.**

## 2.2. Ordering information

| | |
|---|---|
| **SW5002-WgN1(DB)** | 2-ports wireless serial server with D-Sub 9pin serial connector |
| **SW5002-WgN1(TB)** | 2-ports wireless serial server with Terminal Block serial connector |
| **SW5002-WgN1Sis(TB)** | 2-ports RS-422/485 photo Isolated wireless serial server with terminal block serial Connector |

**Optional Accessories**

| | |
|---|---|
| **US315-12 (US)** | AC100~240V US plug / DC12V 3 pin Terminal block for TB model |
| **USE315-12 (EU)** | AC100~240V EU plug / DC12V, 3 pin Terminal block for TB model |
| **1A25F(US)** | AC100~240V US plug / DC12V DC-jack for DB model |
| **1A25F(EU)** | AC100~240V EU plug / DC12V DC-jack for DB model |
| **HG055** | 5.5dBi antenna, SMA (R) Female connector with 180cm cable |

## 2.3. Interfaces

The SW5002 interfaces is shown by **Fig 1.**




DB Model (9 pin D-Sub Connectors)


SMA rev. Antenna Connector
LED indication for Wireless Status
LED indication for Serial Status
LED indication for System/WLAN Status
10/100M Ethernet port for settings
Reset button for restart or factory default
5-pin Terminal Block for Serial port
5-pin Terminal Block for Serial port
3-pin Terminal Block for Power input

TB Model (5pin Terminal Block Connectors)

**Fig 1. SW5002 Interfaces**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## 2.4. Installation Procedures

- Prepare necessary cables, DC power adapter and RS-232/RS-485 connector.
- Place SW5002 under the access point signal coverage area, or connect SW5002 to Ethernet cable with RJ45 connector.
- Connect SW5002 serial port to serial device, make sure the connector and wiring of RS-232 or RS-485 is correct.
- Plug in SW5002 to DC-9-48V power source (with DC-jack or 3-pin terminal bock connector), buzzer will beep and the RUN LED will blink if SW5002 functions normally. For LED Status sees Appendix D4

Use **Monitor.exe** configuration utility on the product CD to check the status of SW5002. If it starts up successfully, User shall find the IP and MAC address of SW5002. User can change IP address, gateway IP address and subnet mask networking parameters of SW5002 according to user networking configurations.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# 3. Software Setup

Now the SW5002 hardware is installed and power is on, network IP configuration will be set in this section.

## 3.1. Default Settings

The SW5002 has two IP addresses one for Ethernet interface and another one for wireless network interface. These default settings are shown from under information

**Default IP addresses**

| Interface | Device IP | Subnet mask | Gateway IP |
|---|---|---|---|
| LAN port | 10.0.0.50.100 | 255.255.0.0 | 10.0.0.254 |
| WLAN Port | 192.168.1.1 | 255.255.255.0 | 192.168.1.254 |

The other default settings of SW5002 are shown in the following table

| Property | Default Value |
|---|---|
| **Ethernet Port** | |
| IP Address | 10.0.50.100 |
| Gateway | 10.0.0.254 |
| Subnet Mask | 255.255.0.0 |
| **WLAN Port** | |
| IP Address | 192.168.1.100 |
| Gateway | 192.168.1.254 |
| Subnet Mask | 255.255.255.0 |
| **Security** | |
| User Name | **Admin** |
| Password | **Null** *(Leave it blank)* |
| **Serial** | |
| COM | 9600/None/ 8/1,No flow control, packet delimiter disabled |
| Link Mode | TCP Server, Listen port 4660/4661,No Filter, Virtual COM disabled |
| **SNMP** | |
| SysName of SNMP | Name |
| SysLocation of SNMP | Location |
| SysContact of SNMP | Contact |
| | |

**Table 1. Default settings of the SW5002 device**

❋ **NOTE: Press reset button for 5 seconds then release the button to restart SW5002 to the default settings.**

❋ **Waring: Please avoid setting LAN and WLAN IP address in the same subnet, that may make unexpect networking problem.**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## 3.2. IP Assignment

### 3.2.1. Configure IP by Monitor.exe utility

Use **Monitor.exe** configuration utility that comes with product CD or diskette to configure the network parameters. For more details, please refer to **Appendix B1**.

**Find new device and IP assignment**

- Use **Monitor.exe** for finding new device IP address, get device's current IP from table list
- Re-assigned IP, network mask and gateway if need with **Monitor.exe**.
- User can configure User ID, Password and Host Name with **Monitor.exe** utility.




**Fig 2. IP settings for Monitor.exe tool**

❋ **Note: All settings were NOT changed if user ID or password was incorrect.**

If there is more than one device using the same IP address in same Subnet. User has to correct mapping between MAC address & IP address by ARP commands.

## ARP commands

ARP (address resolution protocol) commands can be used to assign a static IP address on SW5002 using its hardware MAC (media access control) address. The MAC address"0060E9-xxxxxx" is printed on the rear side of SW5002. The following figure shows how to use ARP command on MS-DOS command prompt window.

**Example**: Set IP **10.0.50.101** to **MAC address 00-60-E9-00-79-F8**.




**Fig 3. Map IP address to MAC address by ARP Command**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

❋ **Note: ARP commands can only be used to set a static IP address of SW5002**

- **arp –a** command show the current mapping IP and MAC addresses.
- **arp –s** "IP address" "MAC address" map the IP address to specify MAC address.

### 3.2.2. Configure IP by web interface

Use common Web browser, ex. Microsoft Internet Explorer or Mozilla Firefox, to configure the network parameters of SW5002.

- Open web browser, type in the **IP address** (default IP: 10.0.50.100) of SW5002 to be configured. Default user name is **admin** and default password is **null** (leave it blank).
- Configure IP settings from web **Network links page** then click "**Save Configuration**" to save settings.
- Click on "**Restart**" button to make the change effective.

Please refer to contents of Web Configuration section for more details.

.

### 3.2.3. Configure IP by Telnet utility

Use common Telnet utility, ex. Microsoft Hyper-terminal, to configure the network parameters of SW5002.

- Run command **telnet "IP address**" to telnet to SW5002 . **Default IP address is 10.0.50.100** and default password is **null** (leave it blank).
- Configure IP settings from **network settings** menu, and **restart** system after saved settings.

Please refer to Telnet Configuration section for more details.

### 3.2.4. Auto IP with DHCP

**DHCP** server will automatically supply an **IP address gateway address**, and **subnet mask** to SW5002. By default, the DHCP client function on SW5002 is disabled, user can activate the DHCP functions by the following steps

- Execute **Monitor.exe**
- Click on the **IP address** (of SW5002)
- Click "***Config***" to pop-up the static IP Dialog Window
- Check on "***Auto IP***"
- Click "***Config Now***" (The SW5002 will restart and obtain the IP from the DHCP server automatically)

## 3.3. TCP/IP Port Number

Default Port numbers of SW5002 is **4660** (1st port) & **4661** (2nd Port) and it is associated with the serial port **COM1** and **COM2** respectively. After the application program connected to the TCP port 4660 (or 4661) on the SW5002, data of user's application program are transmitted transparently to SW5002 and vice versa.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# 4. Application Connectivity

SW5002 provides Tunneling and Virtual COM operation mode. The SW5002 is designed to transmit data between one-or-more serial devices to/from one-or-more TCP/IP devices through **wireless** or **wire** Ethernet, so SW5002 can enhance the accessibility of the serial device through the ubiquitous TCP/IP based Ethernet. The connection distance limit is overcome by SW5002. Examples of these devices are PLC controllers, card readers, display signs, security controls, CNC controller, etc.

## 4.1. TCP & UDP Protocols

SW5002 can be operated in two most common protocols **TCP** and **UDP**.

### 4.1.1. Transmission Control Protocol (TCP)

TCP provides a connection and a byte oriented data stream with control parameters such as flow control, multiple ports option, and order delivery notification. Once the connection is established, data can be transmitted in both directions. TCP guarantees data is transmitted from one node to the other node(s) in orderly. The protocol also distinguishes the transmitted data for different applications (such as a Web server or an Email server) on the same computer.

For redundant or dual-network connectivity purposes, SW5002 offers two TCP operation Modes so users may choose for their specific application, TCP Server Mode and TCP Client Mode.

### 4.1.2. User Datagram Protocol (UDP)

UDP is a faster datagram delivery protocol. User can configure SW5002 to work in the UDP mode. UDP is connectionless protocol and can transmit multicast data to/from a serial device to one/multiple host computer. Because UDP is the connectionless protocol, UDP does not guarantee the reliability and orderly data streams like TCP protocol. Datagram may arrive out of order or lose without notice. But the advantage of UDP is the speed. UDP is faster and hence more attractive in time-sensitive applications.

## 4.2. Connectivity Topology

SW5002 is also equipped with Tunneling and Virtual COM operation modes. It is designed to transmit data to/from multiple serial devices and from/to multiple TCP/IP devices on Ethernet, so it can enhance the accessibility of the serial devices immensely**. Fig 4.** is the example of SW5002 connection topology.




**Fig 4. Typical Topology of SW5002 Connection**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

### 4.2.1. Virtual COM Mode

The **Virtual COM** software emulates a serial port with Internet or LAN topology. In the Virtual COM Mode, COM port data (RS232) is encapsulated to Ethernet data format. By creating a virtual COM port on a PC, the Virtual COM driver redirects communications from the virtual COM port to the destination IP address (and the designated port number) by encapsulated COM data into IP data. **Fig 5.** illustrates a Virtual COM connection diagram.




**Fig 5. TCP Connection in Virtual COM Mode**

### TCP Server in Virtual COM Mode

SW5002 can be configured in the TCP server mode (PC as a client) with a unique IP and Port number, and SW5002 waits passively for the PC to establish a connection to. After the connection is established, PC can communicate to serial devices through SW5002.

### Configure SW5002 to be TCP server

Using one of the three configuration methods (Telnet, Web, and console), User can configure SW5002 to be as TCP Server as following.

- Disabled the IP filter (default)
- Set the port number (default port is 4660 for COM1, 4661 for COM2).
- If IP filter is enabled, only the assigned source IP is allowed to be connected to SW5002.




**Fig 6. TCP Server in Virtual COM Mode**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## TCP Client in Virtual COM Mode

SW5002 can be configured to be TCP Client mode (PC as a server) to establish a TCP connection to an application server on PC, or the Remote Control Host. Once the connection is established, PC or Remote Control Host can exchange data with several serial devices at the same time through SW5002.

## Configuring SW5002 to be TCP client

User can configure SW5002 to be as TCP Client for example, from **Fig. 7**. PC, as a server, has IP address 10.0.0.100 and listening on port 1000. Each SW5002, connected with serial device, configured as TCP client mode with destination IP address 10.0.0.100 and the destination port 1000, and the IP filter is disabled (by default).




**Fig 7. TCP Client in Virtual COM Mode**

## 4.2.2. Tunneling Mode

Tunneling Mode is used for multiple serial devices to “talk” among one another through SW5002’s through wireless LAN or wired Ethernet. This mode is particularly useful when two or more serial devices are far away. This mode can be used to extend the normal serial communication distance of 15 m to 100 m or longer.

One SW5002 can be configured to be the TCP Server Mode with serial device connected and also another SW5002 is configured as TCP client with serial device connected. After the connection is established, both serial devices can exchange data to each other transparently. For example, User can implement SW5002 tunneling mode for Master /Slave mode PLCs or between other serial devices.




**Fig 8. TCP Link in Tunneling mode**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## Configuring SW5002 to Tunneling Mode

Using one of three configuration methods (Telnet, Web, or Console), user can configure SW5002 to TCP Server mode with a desired IP address and port, and with other SW5002 is configured as TCP Clients mode with Server IP and port as destination IP and port respectively.

❋ **Note: TCP client has to assign the destination IP and the destination port corresponding to TCP server's IP and listening port (example: TCP 4660 port).**




**Fig 9. TCP Tunneling Mode**

## UDP

In UDP mode, User may exchange Multicast data from one SW5002 with multiple SW5002s, Vice versa is also true.




**Fig 10. UDP Link in Tunneling mode**

## Configure SW5002 in UDP Mode

Use one of the three configuration methods (Telnet, Web, and console). User can configure SW5002 to UDP mode. In UDP mode, SW5002 can be configured to communicate to more than one node (Multicasting). Note that the **Multicast** IP address is limited by the Class of IP address and subnet mask. As an example, for a network of Class C of subnet 192.168.1.X and a subnet mask of 255.255.255.0, the maximum Multicast IP address to be configured is **four** destinations IP's.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 11. Multi-UDP Link in Tunneling Mode**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# 5. Configure SW5002 by web interface

User has to assign IP address to SW5002 before working on web configuration operations. Please refer to section 3.2 for more detail.

## 5.1. Login to System

Open one of the web browsers, ex. Microsoft IE or Firefox etc. Enter the IP address of SW5002 on the URL. **Example:** *http://10.0.50.100 or http://**user-device-IP***

The following authentication screen shall appear. Enter **user name** and **password** then click on "**OK**". The default user name is **admin** and password is **null** (leave it blank).

**Fig 12. Authorization request for system security**

The overview screen shall appear (**Fig. 13**).

## 5.2. General Information

This system overview window gives the general information on SW5002, included Network, and Serial information.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan



# Overview

The general device information of ATOP-Serial Server.

| Device Information | |
|---|---|
| Model Name | SW5002-WgN1Sis[TB] |
| Device Name | |
| Kernel Version | 1.14 |
| AP Version | 1.22 |

| Network Information | | |
|---|---|---|
| LAN | MAC Address | 00:60:E9:02:2A:69 |
| | IP Address | 192.168.25.77 |
| WLAN | MAC Address | 00:16:E6:3A:79:F0 |
| | Region | Other |
| | IP Address | 192.168.1.1 |
| | Status | PC2TV-0 00:1A:4D:2F:86:AE 45% |

| COM 1 Information | |
|---|---|
| Serial Interface | RS-422 |
| Link Mode | TCP Server |
| Baud Rate | 230400 |
| Parity | |
| Data bits | 3 |
| Stop bits | 1 |
| Flow Control | None |
| Link Status | SERVER MODE |

| COM 2 Information | |
|---|---|
| Serial Interface | RS-422 |
| Link Mode | TCP Server |
| Baud Rate | 230400 |
| Parity | |
| Data bits | 3 |
| Stop bits | 1 |
| Flow Control | None |
| Link Status | SERVER MODE |

Link Status: [N] is the session number connected.
It's [0] when the link is connecting or listening.

Copyright(c) ATOP All right reserved.

**Fig 13. Overview for system information by Web Interface**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## Device Information

SW5002's system information includes **model name**、 **Device Name**、 **Kernel version** and **AP version**. The information is read only and is attributed from another setting page or system status

| Device Information | |
|---|---|
| Model Name | SW5002-WgN1Sis[TB] |
| Device Name | SW5002 |
| Kernel Version | 1.14 |
| AP Version | 1.22 |

**Fig 14. Device Information from Overview web page**

## Networking information

Networking information fields are displayed both '**LAN & Wireless LAN** (WLAN) Information. The information provided **LAN MAC address, LAN IP address, WLAN MAC address, WLAN IP address and WLAN status**

| Network Information | | |
|---|---|---|
| LAN | MAC Address | 00:60:E9:02:2A:69 |
| | IP Address | 192.168.25.77 |
| WLAN | MAC Address | 00:16:E6:3A:79:F0 |
| | Region | Other |
| | IP Address | 192.168.1.1 |
| | Status | PC2TV-0 00:1A:4D:2F:86:AE 45% |

**Fig 15. Network Information from Overview web page**

## Serial Information

SW5002 COM1 (COM2) information includes **UART mode, link mode, baud rate, parity, data bits, stop bits, flow control and link status**. The COM1 (COM2) information is read only and is attributed from Serial settings of COM1 or COM2 Port of SW5002.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

| COM 1 Information | |
|---|---|
| Serial Interface | RS-422 |
| Link Mode | TCP Server |
| Baud Rate | 7 |
| Parity | None |
| Data bits | 3 |
| Stop bits | 1 |
| Flow Control | None |
| Link Status | SERVER MODE |

**Fig 16. Serial Information from Overview web page**

## 5.3. Network Configurations

There are four items allowed to change on Network page, included **LAN, WLAN, DNS** and **SNMP** Information.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan


Network
TCP/IP
To configure network settings of ATOP-Serial Server. After saving configuration you have to restart the device to make the settings effective.
LAN Settings
DHCP
Obtain an IP automatically
IP Address
10 . 0 . 50 . 100
Subnet Mask
255 . 255 . 0 . 0
Default Gateway
10 . 0 . 0 . 254
WLAN Settings
DHCP
Obtain an IP automatically
IP Address
192 . 168 . 1 . 100
Subnet Mask
255 . 255 . 255 . 0
Default Gateway
192 . 168 . 1 . 254
DNS
DNS Settings
DNS1
168 . 95 . 1 . 1
DNS2
0 . 0 . 0 . 0
SNMP
By enabling SNMP you allow the management utility to collect the information of ATOP-Serial Server. You can change the device network identity as well by changing the system name, location and contact.
SNMP Settings
SNMP
Enable SNMP
SysName
0060E9-022A69
SysLocation
location
SysContact
contact
Save

**Fig 17. Network information by Web page**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

### 5.3.1. LAN Settings

**Operation: [Network] → [LAN Setting]**

Click on the "**Network**" link and the following screen shall appear. Fill in IP information on TCP/IP field. Alternatively, click on DHCP to automatically obtain **IP address**, **gateway** and **subnet mask** information.




**Fig 18. LAN Setting from Network web page**

### 5.3.2. WLAN Settings

**Operation: [Network] → [WLAN Settings]**

Click on the ***"Network"*** link Mode and the following screen shall appear. Fill in **WLAN IP** information on WLAN settings fields. Alternatively, User may activate DHCP client function by checking on "***Obtain an IP automatically***" field to automatically obtain **IP address**, **gateway** and **subnet mask** from DHCP server.




**Fig 19. WLAN Setting from Network web page**

### 5.3.3. DNS Settings

**Operation: [Network] → [DNS Settings]**

Click on the ***"Network"*** link and the following screen shall appear. Fill in DNS information on **DNS Settings** field. Alternatively, User can configure DNS by checking on "***Obtain an IP automatically***" field in **LAN Settings** or **WLAN Settings** fields to automatically obtain DNS from DHCP server.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 20. DNS Setting from Network web page**

### 5.3.4. SNMP Settings

### Operation: [Network] → [SNMP Settings]

Click on the ***"Network"*** link and the following screen shall appear. Check on "***Enabling Settings***" field. Fill in desired **SysName**、 **SysLocation**、 **SysContact** information on SNMP Settings fields. The changes of SNMP Settings will take effect only after the SW5002 restarted.




**Fig 21. SNMP Setting from Network web page**

## 5.4. Wireless Configuration

There are three fields of information on Wireless Configuration page which are Default, Current and Site-Survey Information. Click on "***Wireless***" link and the following screen shall appear.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

**Fig 22. Wireless information by Web page**

There are 3 buttons can be operated on Wireless page

- **Rescan:** Click on the "***Rescan***" button, and SW5002 will start site-survey procedures, then on the site-survey list will display the access points founded.
- **Select:** On the site-survey list, click on radio button to attach the access point you wanted
- **User defined:** Users can also define information for wireless parameters by themselves.

### 5.4.1. Wireless Detail Settings

User can configure wireless LAN parameters through web pages. Pop-up windows page will be shown for advanced wireless settings if "**select**" or "**user define**" button was clicked (**FIG. 23**). For example, User can configure **SSID**, **wireless topology**, **Wireless Band Mode**, **TxRate**, **Channel**, **Authentication**, and **Encryption** of the access point that SW5002 want to connect to.

The advanced wireless settings also include roaming threshold. User can configure roaming signal threshold for the SW5002. SW5002 will change to the stronger wireless signal access point, if the original access point's signal is less than roaming threshold.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 23. Pop-up Windows for Wireless Detail settings**

### 5.4.2. Sample Wireless Application Cases

Below are some screen shot examples of **wireless detail settings** for different wireless security schemes.

### Attach access point without Authorization

- **Topology**: Infrastructure
- **Channel**: Auto-assignment from Access point
- **Authentication**: open
- **Encryption**: None




**Fig 24. Open Authorization and no Encryption**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## Attach access point with WEP

- **Topology:** Infrastructure
- **Channel:** Auto-assignment from Access point
- **Authentication:** share
- **Encryption:** WEP
- **WEP Key1~4:** Hexadecimal or ASCII / 64 or 128bit / <WEP Key>




**Fig 25. Share Authorization and WEP Encryption**

❋ **Note1: Enter 5 ASCII value or 10 Hexadecimal digit if select WEP64 encryption.**

❋ **Note2: Enter 13 ASCII value or 26 Hexadecimal digit if select WEP128 encryption**

## Attach access point with WPA-PSK

- **Topology:** Infrastructure
- **Channel:** Auto-assignment from Access point
- **Authentication**: WPA-PSK
- **Encryption**: TKIP or AES
- **WPA-PSK:** 8~ 63 Characters

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 26. WPA-PSK Authorization and TKIP Encryption**

## 5.5. COM Port Configuration

Here User can configure **Serial parameters**, include alias, baud rate, parity, data bit and type of flow control defined by user.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 27. COM port Information Web Page**

### 5.5.1. Link Mode Settings

- Click on the ***"Serial"*** link and the **Fig. 27** screen will appear.
- Fill in Serial parameter information on **Serial Settings** field
- Click on "***Save Configuration***" button to save the changes.

### 5.5.2. TCP Server Mode

**TCP Server** mode is default Link mode of **Serial Settings**, and it can wait for connecting requirement from remote host PC which running "serial-to IP" utility or setting SW5002s in tunneling mode. User has to configure listening port to allow client establish connection to this server. Default port number of SW5002 is 4660.

**IP filtering** function is a simple **ACL** (Access Control List). It can be disabled by setting FILTER_IP to "0.0.0.0".

User can configure one or group IP for **source IP**. If IP filter is enabled, only source IP assigned can be connected to SW5002

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 28. TCP Server in Link mode**

❋ **Note: Enable Virtual COM mode if the remote site PC's "Serial to IP" tool is installed**

### 5.5.3. TCP Client Mode

User may enter destination IP & port (default: 4660) to establish connection of counter-pair (remote) host (For example, another SW5002, or PC for data-collection). SW5002 can support two destination hosts simultaneously.




**Fig 29. TCP Client in Link mode**

### 5.5.4. UDP Mode

SW5002 can be configured in a **UDP mode** to establish connection using **Unicast** or **Multicast** data from the serial device to one or multiple host computers. Vice versa is also true. For example, the original **RS-422/ RS485** bus can be transferred and extended connected distance by SW5002s.

The destination IP is assigned by single IP or group IPs, The configuration is limited by the Local Listening Port. For example, on SW5002 listening port is 4660 which receive data sending from the host computers. SW5002 can support up to **4-group** IPs for UDP connection, if users needed.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 30. UDP protocol in Link mode**

❋ **Note: In this phase, UDP mode does not support Virtual COM mode.**

### 5.5.5. Serial Settings

This filed can be configured with serial parameters for SW5002. Here User can configure Serial parameters, include **UART Mode**, **baud rate**, **parity**, **data bit** and **type of flow control.**

- **Configure UART Mode:** RS-232 or RS-485 or RS-422
- **Baud rate:** 1200/2400/4800/9600/19200/38400/57600/115200
- **Parity:** None or Odd or Even or Mark or Space
- **Data bits:** 7 or 8
- **Stop bits:** 1 or 2
- **Flow control:** None or Xon/Xoff or Hardware (RTS/CTS).




**Fig 31. Serial Communication Settings from Web Page**

❋ **Note: The isolation, SW5002-WgN1Sis (TB), only support max 230Kbps baud rate.**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

### 5.5.6. Delimiter Settings

#### Packet delimiter

Packet delimiter is a way of controlling the number of packets in a serial communication. It is designed to keep packets in track. SW5002 provides two ways in parameter setting: (1) **Packet delimiter by timer** and (2) **packet delimiter by Character pattern**. By default, packet delimiter timer is 10 ms. the range of packet delimiter timer is **10** to **30,000** msec. For Character pattern terminator, if "character pattern is selected and a data stream ended with "0x0a04", then the entire data buffer of the serial device is transmitted.

User can also choose character pattern as the packet delimiter indicated.

## 5.6. Configure System

There are five subsystems for system settings, included **Time**, **WLAN Region**, **Security**, **Set to default** and **Restart**.

**Fig 32. Subsystem menu of system settings Web Interface**

### 5.6.1. Configure Time by NTP Service

**Operation: System→Time**

User can set date and time manually by fill in "***Set Date and Time manually***" field. User can also configure **NTP Server** to obtain Network time automatically.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan


Time
By enabling NTP you allow to adjust and set the device internal time, relative to Greenwich Mean Time.
Current System Time
Tue Mar 7 00:55:46 UTC 2006
Refresh
Enable NTP
Local Time Zone Setting
Time Zone
(GMT+07:00) Bangkok, Hanoi, Jakarta
Sync with Time Server (NTP)
NTP Server
ntp.pbx.org
Enable Manual Setting
Date and Time Settings
Date
Year: 2006 / Month: Mar / Day: 7
Time
Hour:(0~23) : 0 Minute:(0~59) : 55 Second:(0~59): 46
Save Configuration

**Fig 33. Time service settings from System web page**

## 5.6.2. WLAN Region

**Operation: System->WLAN Region**

Click on the "**WLAN Region**" link and the following screen shall appear (**Fig. 34**).

WLAN Region
The default Country is Americas, you can change the Country by selecting.
This item influenced the bands of channel and Wireless Mode.
countryRegion
Americas
Save Configuration

**Fig 34. Time service settings from System web page**

Select the country from drop-down list box to country that user wants to implement the SW5002. This selection will be effected to the bands of channel of SW5002 wireless mode. For example, the normal system level channel configurations for deployments are channels 1, 6 and 11 for FCC countries and 1, 5, 9 and 13 for European Union countries

## 5.6.3. Security (change the Password)

**Operation: System->Security**

Click on the "***Security***" link and the following screen shall appear (**Fig. 35**).

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

Enter the old password on "***Old Password***" field then enter the new password on "***New Password***" and the "***Verified Password***" fields, and then click on "***Save Configuration***" to update the password. The maximum is 8 characters.


Security
The default password is null, you can change the password by filling in the new password to New Password and Verified Password fields, be aware that password is case sensitive.
Old Password
New Password
Verified Password
Save Configuration

**Fig 35. Change password from System Security Page**

❋ **Note: User may press the default reset key to reset password to the default value(blank)**

### 5.6.4. Restoring Factory Default Configurations

**Operation: System→ Set to Default**

User can click on "***set to default and restart***" button to restore SW5002's settings to factory default (**Fig. 36**).

**Fig 36. Set all parameters to factory default by Web Interface**

### 5.6.5. Restart System

**Operation: System→ Restart**

The changes of networking parameters will take effect only after the SW5002 is restarted. User can restart the SW5002 manually by click on Restart button on the restart menu web page (**Fig 37**).

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan


Restart
When the system stops responding correctly, you can perform this.
The restart will be complete when the RUN LED starts blinking.
Restart

**Fig 37. Restart system by Web**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# 6. Telnet Configuration

User can also use Telnet utility to change SW5002 configuration settings.

- Open Ms-DOS command prompt window or other telnet tools
- Enter the "**IP address**" of the SW5002 (For example, **Telnet 10.0.50.100**). The system then prompts for username and password, the default username is "**admin**" and the default password is **null (blank)**.




**Fig 38. Login into System by Telnet**

Then the following main menu shall appear




**Fig 39. Overview information by telnet**

- If the SW5002 does not receive any command within **1 minute**, Telnet will be terminated automatically.
- The changes of networking parameters will take effect only after the SW5002 is restarted.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## 6.1. General Information

**Operation: [Main]→[1 Overview]**

Select "**1**" from "***Input choice (0~6) and enter:***" to enter "**overview page**.

This system overview window gives the general information on **Ethernet & WLAN IP**, **MAC address, SNMP information, kernel and AP version, and the connection status** of the SW5002 (**Fig. 39**).

The following overview information shall appear.

**Device Information:**

**Model Name**: SW5002's Model

**Device Name**: [Allows for changes in SNMP settings]

**Kernel Version**: [Read Only, Generated by system]

**AP Version**: [Read Only, Generated by system]

**Ethernet Information:**

**MAC:** [Read Only]

**IP:** [Allows for changes in Network Page]

**WLAN Information:**

**MAC:** [Read Only]

**IP: [**Allows for changes in Auto IP of Network Page]

**Connected:** [SSID name, if Wireless SW5002 is connected]




**Fig 40. System Information from Overview**

**DNS Information:**

**DNS1: [IP address of 1st DNS Server, Allows for changes in Auto IP of Networking Page]**

**DNS2**: [IP address of 2nd DNS Server, Allows for changes in Auto IP of Networking Page]

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

**SNMP Information:**

**SNMP Status**: Enable [or Disable, Allows for changes in Networking Page]

**SysName**: [Allows for changes in Networking Page]

**SysLocation**: [Allows for changes in Networking Page]

**SysContact**: Allows for changes in Networking Page]

**Serial Information:**

**UART** mode RS485/RS232/RS422

**Link Mode**: TCP Server [or TCP Client/UDP Mode, Allows for changes in Serial Page]

**Baud rate**: 115200 [or 1200/2400/4800/9600...Allows for changes in Serial Page]

**Parity**: None [or Even/Odd/Space/Mark...Allows for changes in Serial Page]

**Data bits**: 8 [or 7 (bits).Allows for changes in Serial Page]

**Stop bits** 1 bit or 2 bits

**Flow Control** None, Xon/Xoff, RTS/CTS

## 6.2. Networking Configuration

**Operation: [Main]→[2 Networking]:**

Select "**2**" on "**Input choice (0~6) and enter**:" to enter **Networking settings** page.




**Fig 41. Networking Settings by Telnet**

❋ **Note: Press "0" key to return to the previous menu**

This section allows for changes in **IP address, subnet mask, gateway IP address and SNMP** information. Please note that setting changes will not take effect until the SW5002 is restarted.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

### 6.2.1. LAN Settings

**Operation: [Main]→[2 Networking]→[1 LAN Settings]**

Select "**1**" from "***Input choice (0~3) and enter on Networking page:***" to enter **LAN Settings page**. The **MAC address**, **IP address**, **subnet mask**, **gateway address**, and **IP mode information** will be shown (**Fig. 42**). User also can set **IP, Netmask, Gateway, and IP mode** of **LAN interface**s by enter the corresponding menus and values. For example, **enter 1** for setting the **IP address** on LAN interface.




**Fig 42. LAN Settings by Telnet**

### 6.2.2. DNS Settings

**Operation: [Main]→[2 Networking]→[2 DNS Settings]**

Select "2" from "***Input choice (0~3) and enter on Networking page:***" to enter **DNS Settings page.**

Fill in the DNS information DNS1 or DNS2 or both according to user DNS server (**Fig. 43**).




**Fig 43. DNS Settings by Telnet**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

### 6.2.3. SNMP Settings

**Operation: [Main]→[2 Networking]→[3 SNMP Settings]**

Select "**3**" from "***Input choice (0~3) and enter on Networking page***:" to enter **SNMP Settings page.** User can enable/disable SNMP, and set network identification information on **SNMP Settings page.** The changes will not become effective until SW5002 is restarted

SW5002 basically supports get/set SNMP parameters, these are **SysName** (System Name), **SysLocation** (System Location) and **SysContact** (System Contact). These fields will response and supply basic system information from standard SNMP query. User can set the SNMP system parameters by enter the corresponding menus and values. For example, **enter 2** for changing the **SysName** then enter the desired name.




**Fig 44. SNMP Settings by Telnet**

## 6.3. Wireless Configuration

**Operation: [Main] → [3 Wireless Settings]**

Select "**3**" from "***Input choice (0~6) and enter***:" the following screen shall appear (**Fig. 45**).

User can configure wireless **IP, Netmask, Gateway**, **IP mode**, and **Region** by enter the corresponding menu and corresponding values.




**Fig 45. Configure Wireless Settings by Telnet**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

### 6.3.1. Wireless IP, Netmask, Gateway and IP mode Settings

**Operation: [Main] → [3 Wireless Settings]→ [1 IP]/[2 Netmask]/ [3 Gateway]/[4 IP Mode]**

User can configure SW5002 **Wireless IP/Netmask/Gateway** by enter **1/2/3** at **Wireless Settings page** and enter the desired **IP/Netmask/Gateway address**.

User can also configure **wireless IP mode** by enter **4** at **Wireless Settings page** and enter **1 for static IP** address or enter **2 for DHCP** mode (**Fig. 47**).




**Fig 46. Configure Wireless Networking by Telnet**




**Fig 47. Configure Wireless IP mode by Telnet**

### 6.3.2. Configure Region

**Operation: [Main] → [3 Wireless Setting] → [5 Region]**

WLAN Region is the geography area that user want to implement the SW5002. Because the wireless channel implement the frequency band differently in a different regions. User can configure the **WLAN Region** by **enter 5** at **Wireless Settings page** and enter the menu according to user's region.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 48. Wireless Region by Telnet**

## 6.3.3. Site Survey

**Operation: [Main] → [3 Wireless Setting] → [6 Site Survey]**

Site survey function can support to auto-assignment wireless parameters, and attached to access point selected automatically. After user do the **site survey** the result of all access points nearby will be displayed (**Fig.49**). Then user can select the access point that user want SW5002 to be connected to by enter the number of access point (**Fig. 50**).




**Fig 49. Wireless AP List from Site Survey**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 50. Connected to AP from Site list**

## 6.3.4. Manual Wireless Settings

**Operation: [Main] → [3 Wireless Setting] → [7 Manually Settings]**

User can manually configure SW5002 wireless configurations by enter 7 at the Wireless Settings page. Then user can set any wireless parameters by enter the menu corresponding to that parameters. Wireless parameters are shown in **Fig. 51** below.




**Fig 51. Configure Wireless LAN by Manual**

## 6.3.5. Configure Ad-Hoc Mode

**Operation: [Main] → [3 Wireless Setting] → [7 Manually Settings] → [2 Topology]**

Independent Basic Service Set (IBSS), the most basic type of IEEE 802.11 wireless LAN, is commonly referred to as an ad-hoc network. An IBSS may consist of as few as two stations. Unlike infrastructure mode, all stations are capable of communicating directly with each other without access point.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

User can configure Wireless SW5002 to be Ad-Hoc mode, by manually configure the wireless **network topology** as shown in **Fig.52** below.




**Fig 52. Configure Ad-Hoc mode by Telnet**

User can select wireless link by none or WEP encryption in Ad-hoc mode and these encryptions can support applications from customer's requirements.

## Configure Wireless for WEP

**Operation: [Main] → [3 Wireless Setting] → [7 Manually Settings] → [8 Encryption Type]**

For security reason, Wireless SW5002 can configure to use **WEP key** of **40 bits or 128 bits**, or advance **WPA-PSK** to securely communicate in the wireless network. WEP key manually configure via telnet screen is shown as **Fig. 53** below.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 53. Configure WEP 64 bits Settings in Ad-Hoc mode with open key**

- **Note1: Enter 5 ASCII value or 10 Hexadecimal digit if select WEP64 encryption.**
- **Note2: Enter 13 ASCII value or 26 Hexadecimal digit if select WEP128 encryption**

## 6.3.6. Configure Infrastructure Mode

**Operation: [Main] → [3 Wireless Setting] → [7 Manually Settings] → [2 Topology]**

The 802.11 infrastructure networking framework is the framework which devices communicated with each other have to connect to an Access Point (AP) first before connect to the other devices.

Wireless SW5002 supports different type of authorizations in infrastructure modes; include Open system, shared encryption with WEP64/128, WPA-PSK, from wireless encryption features.

The Figures below are some screen shot schemes for different authorized modes.

**Settings with open authorization and none encryption**

- **Topology:** Infrastructure
- **Channel:** Auto-assignment from Access point
- **Authentication:** open
- **Encryption:** None

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 54. Wireless: Open authorization and none encryption**

**Configure share authorization with WEP encryption**

- **Topology:** Infrastructure
- **Channel:** Auto-assignment from Access point
- **Authentication:** shared
- **Encryption:** WEP




**Fig 55. Wireless: Share authorization and WEP encryption**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

**Configure wireless network via access point with WPA-PSK**

- **Topology:** Infrastructure
- **Channel:** Auto-assignment from Access point
- **Authentication:** WPA-PSK
- **Encryption:** TKIP or AES
- **WPA-PSK:** 8~ 63 Characters




**Fig 56. Wireless: WPA-PSK authorization and TKIP encryption**

## 6.4. COM Port Configuration

User can configure serial parameters, include COM1(COM2) **operation mode**, **port parameters**, **enable or disable serial buffer**'s data and **packet delimiter**.




**Fig 57. Select COM Port from Serial Settings by Telnet**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 58. The COM1 Setting page**

### 6.4.1. TCP Server Mode for Link Mode

**Operation: [Main] → [4 Serial Settings] → [1 Link mode] → [1 TCP Server]**

TCP Server mode is **default** setting for Link mode of serial settings of SW5002, and it can be configured to wait for the host computers to establish a connection with the serial device through SW5002. SW5002 needs to be configure the listening port to waiting for host connection, Default Port number of SW5002 is 4660 (4661) and it is associated with the serial port COM1 (COM2). After the connection is established, data can flow in both directions. SW5002 can wait for connection requested from remote PC which installed **"serial-to IP"** tool or counter-pair SW5002 in **tunneling mode**. After the application program being connected to the TCP port 4660 (4661) on the SW5002, data of user application program are transmitted transparently to serial devices through SW5002 and vice versa.

User enters 1 at COM1 (COM2) Settings page and enters 1 for the TCP Server mode. To enable the remote client which install "**serial-to IP**" to connect to SW5002, user has to **enable** the **Virtual COM** and Set up the designated **port** number.

**IP filtering** menu is a simple **ACL (Access Control List)**. It can be disabled by setting **FILTER_IP** to **"0.0.0.0"**. User can configure one or group IPs for source IP in IP filtering. If **IP filtering** is **enabled**, only **source IP** assigned can connect to SW5002.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 59. TCP Server mode in link mode**

❋ **Note: Enable Virtual COM mode if the remote site PC's "Serial to IP" tool is installed.**

### 6.4.2. TCP Client for Link Mode

**Operation: [Main] → [4 Serial Settings] → [1 Link mode] → [2 TCP Client]**

User can configure SW5002 to work in TCP Client mode. On destination IP & port (default: COM1:4660/COM2:4661), Enter the desired destination IP and port (Server IP and port) that SW5002 want to connect to (For example, another SW5002, or PC for data-collection). The SW5002 can support two destination host computers simultaneously. **Fig. 60** is the **TCP Client** page.




**Fig 60. TCP Client mode in link mode**

### 6.4.3. UDP for Link Mode

**Operation: [Main] → [4 Serial Settings] → [1 Link mode] → [3 UDP]**

SW5002 can be configured to work in UDP mode to establish connection using **Unicast** or **Multicast**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

protocol. Data can be transmitted from one or multiple serial devices to/from one or multiple host PCs and vice versa. For example, the original RS-422/ RS485 bus data is transferred over the extended connected distance by SW5002s, The destination IP is assigned by single IP or group IPs, The configuration is limited by the Local Listening Port, default 4660 and 4661 on the COM1 and COM2 of SW5002.

SW5002 can support up to 4-group IPs for UDP connection, if users needed.




**Fig 61. UDP mode in link mode**

❋ **Note: In this phase, UDP mode does not support Virtual COM mode.**

### 6.4.4. Serial Settings

**Operation:**

**[Main] → [4 Serial Settings] → [2 Baud rate]/ [3 Parity]/[4 Data bits]/ [5 Stop bits]/ [6 Flow control]**

User can configure **baud rate**、**data bits**, **parity**、**stop bit** and type of **flow control.**




**Fig 62. Serial Settings by Telnet**

❋ **Note: The isolation one, SW5002-WgN1Sis (TB), only supported max 230Kbps baud rate.**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

### 6.4.5. Packet Delimiter

**[Main] → [4 Serial Settings] → [8 Delimiter (Network to Serial)]/ [9 Delimiter (Serial to Network)]**

Packet delimiter is a way of controlling the number of packets in a serial communication. It is designed to keep packets in track. SW5002 provides two ways in packet delimiter parameter setting: (1) Packet delimiter **by timer** and (2) Packet delimiter **by character**. By **default, packet delimiter timer is 10 ms**. The ranges of packet delimiter timer is 10 to 30,000 ms, If "character pattern' is selected, for a data stream ended with "**0x0d0a"**, then the entire data buffer of the serial device is transmitted.

User can change packet delimiter timer by following the steps below.

## Configure Network Delimiter using Timer

**[Main]→[4 Serial Settings]→ [8 Delimiter (Network to Serial)]/ [9 Delimiter (Serial to Network)] →[1 Timer]**

User can choose **packet delimiter timer**'s value as the packet delimiter indicated in **Fig. 63** below




**Fig 63. Configure Network Delimiter using Timer**

## Configure Network Delimiter using Characters

**[Main]→[4 Serial Settings]→ [8 Delimiter (Network to Serial)]/ [9 Delimiter(Serial to Network)] →[2 Characters]**

User can choose **packet delimiter character** pattern as the packet delimiter indicated in the **Fig. 64** below:

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 64. Configure Network Delimiter using Characters**

## 6.5. Security Configuration

**Operation: [Main] → [5 Security]**

User can change password of SW5002 with this menu.




**Fig 65. Security settings by Telnet**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

### 6.5.1. Change the Password

**Operation: [Main] → [5 Security]→ [1 Change Password]**

Enter desired password on "**New password**" fields.




**Fig 66. Changing the Password by Telnet**

❋ **Note: User may press the reset key on the product to reset to default password(blank).**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# Appendix A. Using Virtual COM

**Virtual COM** driver mode for windows converts COM port data (RS232) to IP data to control the RS-232C port on a SW5002 over the IP network. By creating Virtual COM ports on the PC, Virtual COM redirects the communications from the Virtual COM ports to an IP address and port number on a SW5002 which connected to the serial devices. The following figure is Virtual COM connection diagram.




**Fig 67. Setup of a Virtual COM driver**

## A.1. Pre-installation Requirements

Please check the operating system on your PC complied with the following requirements:

- Processor: Intel-compatible, Pentium class
- Operation system: Windows Server 2003, Windows XP, Windows 2000, Windows NT 4.0 SP5 or later, Windows Me, Windows 98, Windows 95, Microsoft NT/2000 Terminal Server, Citrix Meta Frame
- Windows Installer 2.0
- Network: Microsoft TCP/IP networking software

## A.2. Applying to the SW5002

### Limitation

Virtual COM driver provides user to select up to **256 COM ports** as Virtual COM ports in a monitoring PC. User can select them from a list of COM ports, which is from COM1 up to COM256.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

### Installation

Make sure you have turned off all anti-virus software before beginning the installation. Run Vcom.exe program included in the CD to install Virtual COM for your operating system.

In the end of the installation, please select one or two COM ports to become the Virtual COM ports.

### Uninstalling

- From Windows Start menu, select Setting\ Control Panel\ Add/Remove Programs.
- Select Serial IP for in the list of installed software.
- Click the Add/Remove button to remove the program, or From Windows Start menu select Programs, Serial IP click Uninstall Serial IP to remove the program.

## A.3. Virtual COM Communication

### Enable Virtual COM on SW5002 by web interface

From web browser access to SW5002 by typing its IP address, click on "***Serial***" link to access Serial page, on the top half of the page click on "***TCP Server***" and enable Virtual COM by putting a check in front of the "**Enable**" checkbox, then type in the local port number in the "***Local Port***" field as indicated in the following screen.




**Fig 68. Enable Virtual COM Mode by Web page**

### Enable Virtual COM on SW5002 by Telnet

User may also enable Virtual COM through telnet by setting Serial as a TCP server, and enter the local port number for Serial, then enable virtual COM as shown in the following procedure:

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## Login SW5002 via Telnet




**Fig 69. Login into SW5002 by Telnet or Console**

Select **serial setting** for TCP server/Client, and enabling Virtual COM mode




**Fig 70. Enable Virtual COM mode by Telnet**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## Running Serial to IP for program on monitoring PC

On Window Start Menu, **go to\program\Serial/IP\Control panel**, The "Serial to IP for Control Panel" window shall appear. Then select the serial port.




**Fig 71. Detail setting from Serial/IP**

On the right of the panel is a sample for COM 4 settings. On the left is the list of the COM ports that have been selected (on **Select Ports** window) for use by the Virtual COM Redirector. Change the list by clicking the **Select Ports** button.

Each COM port has its own settings. When click on a COM port, the Control Panel changes to reflect that the selected port.

❋ **Note: COM port changes become effective immediately.**

## Configure Virtual COM Ports

Serial/IP COM port can be changed as follows:

- Select a COM port on the list.
- On **IP Address of Server**, enter SW5002 IP address.
- On **Port Number**, enter the TCP port number of the SW5002.
- On **Server Credentials**, the default is **No Login Required**. If the SW5002 does require login by the Virtual COM Redirector, the Virtual COM Redirector must provide a username and/or password every time an application tries to access the SW5002.
- Click the **Configuration Wizard** button and then click the **Start** button that shall appear on the wizard window. This step verifies that the Virtual COM Redirector communicates with the SW5002. If **Log** display does not show errors, click **Use Settings**, return to the Control Panel
- Settings on the **Connection Protocol** must match the TCP/IP protocol supported by the SW5002. The Configuration Wizard is capable of determining the correct settings.
- On **COM Port Options**, the settings must match the COM port behavior expected by the PC application. The Configuration Wizard will recommend such settings.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 72. Configuration Wizard from Serial to IP tool**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# Appendix B. Configuration Utility & SNMP

## B.1. Monitor.exe

The configuration utility is the main utility program used to display and to configure SW5002's settings.

### Run the utility

Start the program under environment and the following window shall appear.




**Fig 73. Device list from Monitors Configuration Utility screen.**

### Detecting Operational Devices

Follow steps below to detect all devices currently available on the network.

- Start **monitor**XX**.exe** utility program.
- Select an item from the **Broadcast IP** list.
- Specify a number on **Wishes** box.
- Click on the **Invite** button. This will display all the devices requested.

### Configure Devices

Use **monitor.exe** to configure the settings of devices on the network. To do so, please follow the steps below.

- Bring up devices information by executed monitor.exe
- Select the device to be configured from **IP Address**, Click on the "***Config*"** button, a configuration dialog box will popup as shown in **074**.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 74. Configure Device by utility**




**Fig 75. Change settings by Monitor.exe**

Clicking on the "***Configure Now***" button, the target device return an ACK message indicating the modification is successful as shown follows.

**Fig 76. "Ack" message from monitored device**

.

## Functional description

The following table lists the functional descriptions for each field.

| Field Name | Field Descriptions |
|---|---|
| **Broadcast IP** | Except for the default IP 255.255.255.255, other items (IPs) are read from the file "seg.cfg". This field specifies a detecting IP range. It may be a designated IP or a broadcast IP. |

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

| | |
|---|---|
| **Wishes** | Specifies minimum number of the devices you wish to get reply from after sending an **Invite** request. If there is not as many as devices responding to your invitation, the system repeatedly sends invitation until your request is fulfilled. |
| **Reply** | Indicates the actual number of devices this utility program detected. |
| **Retry** | Specify the number of times that an Invite request is re-sent. |
| **Locate** | Locate the specified device by sound identification (Beep) |
| **Reset** | Reset the selected device. |
| **Config** | Configure the selected device. |
| **Exit** | Exit this utility. |
| **IP Address** | Indicate the IP address of the device that replied to your request.<br>Leading tag "!" stands for IP address collision, possibly caused by duplicated IP addresses on the network.<br>Leading tag "?" stands for Mac address collision, possibly caused by duplicated Mac addresses on the network. |
| **MAC Address** | Indicates the MAC address of responding device. |
| **Gateway** | Indicates the IP address of the gateway. |
| **Subnet Mask** | Indicates the TCP/IP network mask. |
| **OS** | Indicates the OS version of the responding device. |
| **AP Version** | Indicates the AP version of the responding device. |
| **Model** | Indicates the model number of the responding device. This field is only available for monitor.exe version 2.0 and above. |

## B.2. SNMP Network Management Platform

SW5002 is an SNMP device that allows many popular SNMP network management platforms such as **HP OpenVie**w and **SunNet Manager** or other ones to conduct monitoring on the device. Depending on the network management tools used SW5002 information can be collected from running the management tools including IP address, DNS name, system descriptions and NIC information.

## B.3. An Example: Using NetworkView

**NetworkView** is a free compact network management tool from NetworkView Software, Inc. (www.networkview.com). It discovers all TCP/IP nodes in a network using DNS, SNMP and ports information and documents with printed maps and reports for future use.

First, download and install the tool on ones PC (**Windows 2000 and Windows XP**), then start NetworkView.

Click on the button to open a new file. The following screen shall appear, on **Addresses field**, Enter in the IP address range for searching.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan




**Fig 77. IP address searching**

Click on “OK” and the following dialog box shall display the searching progress




**Fig 78. Searching progress**

After the search is complete, NetworkView will display the devices found on the main window, as shown below




**Fig 79. NetworkView displays the founded devices**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

Double-click on the device icon to display information about the device, including IP Address, Company, SysLocation (Max 15 characters), SysName (Max 9 characters) and types etc.




**Fig 80. NetworkView displays device information**

❋ **Notes1: NetworkView is limited to information extracting and viewing only. To modify the configurations, use the web server, Telnet or monitor.exe configuration utilities.**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# Appendix C. Upgrading System Software

Updated version of firmware can be downloaded from www.atop.com.tw.

## C.1. System Upgrading Procedures

Follow the upgrading procedures below for the latest firmware.

- Make sure the PC and SW5002 on the same network. Use command "**ping**" or "**monitor.exe**" utility program to verify their availability
- Edit "dll.bat " to fit the system requirements, Be sure to save all modifications
- Run dll.bat ,or type command and parameters by linux_dl_v2.exe, the following screen shall appear:

  *linux_dl_v2.exe zImage.bin 10.0.152.100* (device's IP is 10.0.152.100)

❋ **Tips : "linux_dl_v2.exe" is the upgraded executing file(can find on setup cd) and zImage.bin is the name of the firmware file; xxx.xxx.xxx.xxx is the IP address of SW5002.**

❋




**Fig 81. Start firmware upgrade perceudre for SW5002**

SW5002 shall automatically perform the download at first phase, and restart after downloaded process at secondary phase




**Fig 82. Connected & downloading process for SW5002's Upgrade**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## C.2. Critical Issues in Upgrading Process

If the upgrading is successful, SW5002 shall re-program the flash memory, and the buzzer will beep before restarting. It takes around 5 seconds to complete the re-programming. **If an error occurs during the process, SW5002 will clear the corresponding memories, and the system will remain the same as the one before the upgrading process**.

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

# Appendix D. Specifications

## D.1. Hardware Specifications

| | |
|---|---|
| **System** | |
| CPU | 150MHz RISC with MMU support |
| Memory | Flash: 8MB, 2MB for Bootloader /<br>SDRAM: 16MBytes. |
| Interface | Mini-PCI Slot (for Wireless Module) |
| Watchdog | Hardware Watchdog Reset |
| Debug Port | CPU Build in Com. |
| **Wireless LAN** | |
| Protocols | Compliance for IEEE802.11b/g<br>Modulation Type: CCK, DQPSK, DBPSK, OFDM (11g) |
| Topologies | Infrastructure, Ad-Hoc |
| Security | WEP 64-bit/128-bit data encryption<br>WPA Compatible (TKIP/AES Encryption) |
| RF Performance | Tx Power 11b: 14dBm / 11g: 13 dBm<br>Rx Sensitivity: -66 dBm @ 54 Mbps, -80 dBm @ 11Mbps<br>Transmission Rate: 54 Mbps (max.) with auto fallback<br>Transmission distance: Up to 300 meters (@12 Mbps, in open areas)<br>Mobile for Fast Roaming |
| Interfaces | Reverse SMA Connector for Antenna |
| **Network** | |
| Protocol | 10/100M Auto-Negotiation Fast Ethernet |
| Interface | RJ-45 Connector with 2LEDs<br>Protection: Built-in 1.5 KV magnetic isolation |
| Application | Configuration with Telnet Protocol |
| **Serial** | |
| Protocols | Support RS232/485/422 & Software Selection |
| Interface | Terminal Block Connector –TB model (with 12KV ESD)<br>D-sub 9-pin Connector –DB Model (with 12KV ESD) |
| Parameters | Baud Rate: 1200~921Kbps<br>Parity Check: None/Odd/Even/Mark/Space<br>Data Length: 7/8 Bit<br>Stop Bit: 1/2<br>Flow Control: None/ Software: Xon/Xoff / Hardware: RTS/CTS |
| **Power** | |
| Input | DC 9V-48V |
| Consumption | 4.5 W max @Tx Mode |

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

| | |
|---|---|
| **Mechanical** | |
| Dimensions | HxWxD: 90mm x 45mm x 75mm |
| Casing | Metal Housing for IP50 Standard |
| **Environmental** | |
| Operating Temperature | 0 to 65°C (32 to 140°F), 5 to 95% RH |
| Storage Temperature | -20 to 85°C (-4 to 185°F), 5 to 95%RH |
| **Regulatory Approvals** | |
| EMC | FCC/CE |
| Safety | UL |
| Warranty | 5 Years |

## D.2. Software Specifications

| **Software** | |
|---|---|
| Protocol | ICMP, IP, TCP, UDP, DHCP Client, Telnet, DNS, SNMP, HTTP, SMTP, SNT |
| Utility | Virtual COM Utilities for Windows 98/2000/XP/2003/Vista |
| | Configure Utilities: Supported for Windows 98/2000/NT/XP/2003/Vista |
| Configuration | Web browser |
| | Telnet Console |
| | Windows utility |
| Buffer Size | TCP receiving buffer size = 8K bytes |
| | TCP transmitting buffer size = 16K bytes |
| | RS-232/RS-485 receiving buffer size = 4K bytes |
| | RS-232/RS-485 transmitting buffer size = 4K bytes |

## D.3. Pin Assignments

DB9 male connector pin assignments for Serial

| DB9 | | | | |
|---|---|---|---|---|
|  | **Pin#** | **RS-232** | **RS-485** | **RS-422** |
| | **1** | DCD | | |
| | **2** | RXD | | T+ |
| | **3** | TXD | Data+ | R+ |
| | **4** | DTR | | |
| | **5** | SG (Signal Ground) | | |
| | **6** | DSR | | |
| | **7** | RTS | Data- | R- |
| | **8** | CTS | | T- |
| | **9** | RI | | |



Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

Terminal block pin assignments for Serial and Power

| 5-pin for serial connections | | RS-232 | RS-485 | RS-422 | 3-pin for Power input | | |
|---|---|---|---|---|---|---|---|
|  | **SG** | GND | GND | GND |  | **FG** | FG |
| | **RTS/R-** | RTS | Data- | R- | | **Vin-** | GND |
| | **TxD/R+** | TxD | Data+ | R+ | | **Vin+** | 9~48V |
| | **CTS/T-** | CTS | | T- | | | |
| | **RxD/T+** | RxD | | T+ | | | |

❋ **Note: RS-485 2 or 4 pins assignments of DB9 connector are different from those of Mini DIN connector.**

## D.4. Beep & LED Status

### Startup status

| Message | | Description |
|---|---|---|
| **^==^========^^^** | (5sec) | Startup OK and AP firmware is enabled |

❋ **Buzzer indication: " ^ " : Beep twice " = " : Beep off**

### Wireless Signal Strength status

The BSS quality can be detected by LED indicator on SW5002. On running time, pressed default key and then released, one of the specified actions below shall be done that depend on the released time after you heard how many beeps. BSS quality is indicated by count of LEDs as shown below.

### RSSI LEDs Message:

○ Off ● On ☼ blinking

| Operations | | Status* | LED1 | LED2 | LED3 | LED4 | LED5 |
|---|---|---|---|---|---|---|---|
| **Connecting** | Search AP (sequentially blinking) | ☼ | ☼ | ☼ | ☼ | ☼ | ☼ |
| | Connected AP/ Get assigned IP | ☼ | ☼ | ☼ | ☼ | ☼ | ☼ |
| | Not matched SSID | ☼ | | | | | |
| | Not available IP | ☼ | ☼ | | | | |
| **Connected** | Signal Strength is less 20% | ● | | | | | |
| | Bad Signal Strength (20%) | ● | ● | | | | |
| | Poor Signal Strength (40%) | ● | ● | ● | | | |
| | Fair Signal Strength (60%) | ● | ● | ● | ● | | |
| | Good Signal Strength (80%) | ● | ● | ● | ● | ● | |
| | Excellent Signal Strength (100%) | ● | ● | ● | ● | ● | ● |

❋ **Note: The lowest LED is indicated for STATUS at SW5002's front plate.**

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan

## WLAN LED Message

| Message | Description |
|---|---|
| LED Off | No data is transmitting on Ethernet |
| LED blinking | Data is transmitting on Ethernet |

## COM Port LED Message

| Message | Description |
|---|---|
| LED off | No data is transmitting on COM port |
| LED on blinking state | Data is transmitting on COM port |

## RUN LED Message

| Message | Description |
|---|---|
| LED blinking (rate: 0.5Sec) | AP firmware is running |

Copyright © 2007 Atop Technologies, Inc.
All rights reserved. Designed in Taiwan